

WiTrace

INSTALLATION GUIDE



RUCKUS APS
Integration Guide

WiTrace by Foot Analytics

Last revision
November 2022

Configuration

In System > General Settings

For configuring the integration with Ruckus APS, follow the next steps:

1. Click on **Access Points** on left menu.
2. When loaded, click the zone that you want to connect (2) and then press the edit button (3):

Virtual SmartZone - Essentials

Dashboard

System

- General Settings
- Switch Settings
- AP Settings
- Cluster
- Maps
- Certificates
- Templates
- Access Points 1**
- Switches
- Wireless LANs

Access Points (2) 1 Online 0 Flagged 1 Offline

System > Default Zone

+ [edit] [delete] [More] [Refresh] [Back] [Configure] [Move] [Delete] [More]

- D System +
- + Z Default Zone 2

| MAC Address | AP Name | Status |
|-------------------|----------|---------|
| 44:1E:98:35:5B:40 | RuckusAP | Offline |
| EC:58:EA:2D:71:C0 | RuckusAP | Online |

General Configuration Health Traffic Alarm Event Clients Wired Clients WI

Group Info

Name Default Zone

3. A settings pop-up will appear. Then you must go to the **Advanced Options**, enable the **Location Based Service** and select (or create) the venue.

